

Parametry Denavita-Hartenbarga dla Manipulatora ABB IRB120

Ogniwo	a_i	α_i	d_i	θ_i
1	0	$-\frac{\pi}{2}$	d_1	q_1
2	d_2	0	0	$q_2 - \frac{\pi}{2}$
3	d_3	$-\frac{\pi}{2}$	0	q_3
4	0	$\frac{\pi}{2}$	d_4	q_4
5	0	$-\frac{\pi}{2}$	0	q_5
6	0	0	d_5	q_6